

1. Front Side, leave 6 holes before the cub



2. Rear (back) side, leave 5 holes before the cub



3. Fix the two cubs on one horizontal rail, then fix the vertical rails on the cubs to make sure 19 inch



4. Fix the vertical rails with screws

